NEW REALMS IN CLASSIC SEISMIC INSTRUMENTATION



MONITORING A RESTLESS EARTH "SPIN : S eismological P arameters and In strumentation"



Advancement Through Innovation | © 2021 Kinemetrics





EDELVAYS SPASSOV KINEMETRICS INC.



KINEMETRICS – MORE THAN JUST GOOD INSTRUMENTS

Established in **1969**, Kinemetrics & its subsidiaries have been the global market leaders in designing technologies, products, and solutions for monitoring seismic events and their effects on people and structures.

Kinemetrics offer the least expensive **Total Cost of Ownership** (TCO), with not only the initial cost of purchase, but also the accumulated costs of nonfault operation, maintenance, troubleshooting, repair and related sites visits and **no loss of data** due to equipment failure.



QUANTERRA[®]











KINEMETRICS' PRODUCTS EVERYWHERE!

We are the only company with over 50 years on the market, the only company, which very successfully operates 450 stations critical operations network since 2012, and the only company with sensor on Mars.







KINEMETRICS IN SPACE

NASA InSight Lander reached Mars on November 26, 2018 and started recording continuously from Sol4

SP was switched on also during the flight and the horizontal sensors recorded "ambient" noise - the lowest noise possible

Although called Short-Period, it's a wideband 10 s – 100 Hz seismometer

Rugged, designed to withstand takeoff & landing accelerations, strong flight vibrations, as well high cosmic radiation

Designed to operate at -65 degrees Celsius and with 15 degrees tilt

Advancement Through Innovation | © 2021 Kinemetrics



SEIS-SP Seismometer on Mars





MORE INSTRUMENTS TO SEND IN SPACE!

The Lunar Seismic Package (LSP) evolved from the InSight Short Period (SP) seismic sensor and Back End Electronics (BEE). Planned to land on the **Moon**.

LSP Sensor Package Optimization for Lunar Missions:

- Triaxial, Identical Sensors
- Lower noise than InSight SP
- **Enhanced Calibration**
- Sensor head, proximity electronics and magnets can be packed in ~50 mm cube ~650 g for sensor+feedback (triaxial)
- 360 mW for sensor+feedback (triaxial)
- Does not require leveling in lunar gravity







Kinemetrics Digitizers - NO Data Gaps USArray Data Continuity







Amazing Progress Since 1990

2020

More than 7,000 units in the field

The newest "Q8", on top of the Pile:

- Samples 20 × the data rate
- Stores 1000 × the data
- In a volume 50 × smaller
- Consumes 100 × less power
- Compared to "Q680" data system of 1990 (bottom)

a combined factor **100,000,000 x**"better" than the systems of 1990. 1990







New Q8 & Pebble Digitizers

Built for the future on your successful partnership with Kinemetrics

A Trilogy of Trust



<0.5 kg;





What Is Q8?

- Feature-packed, higher-performance Ultra Low Power replacement of Q330!
- Web-based operation and control no cable required
- WiFi, Ethernet and Mesh communication interfaces
- Multiple (4) High-Integrity Storage Media (internal 32GB eMMC plus internal and removable USB flash drives and an internal SD card up to 256GB)
- Universal serial sensor interface
- GNSS timing or external timing (PTP) via RS-485
- Streaming low-latency (<1s) data packets for EEWS applications
- Antelope & Seedlink compatibility

Q8 employs an 8-th generation (hence the name, Q8) "floating point" ADC converter, not limited to 32-bits.





WiFi ON Button

This button is the main user control and performs 3 functions: In cycled recording mode, a brief (~½ sec) press will power up the recorder and activate the WiFi AP. If the recorder is powered, and the WiFi is off, a brief press will turn on the WiFi. If the WiFi is already on, a brief press will power down the recorder.







KINEM

- **4 x real-time telemetry options**: Q8's native "Q660 Protocols", Seedlink, and BRTT Antelope, QSCD2.0.
- **4 x "archival" devices** available: SD card, eMMC, internal USB drive, and external USB drive. In addition, the "Deep Packet" Buffer" may be stored in RAM or on the SD card
- A **built-in accelerometer** with resolution level ~1mg, can also be used as a tamper detector, orientation detector (tip/tilt) and/or with the "wake on shake" function.
- * "Wake on Shake" function. This wakes the system if the internal accelerometer exceeds a specified threshold, if unit is in cycled operation mode.
- "High Resolution" mode combines all 6 physical A/D channels to provide 3 data channels with an improvement of roughly 3dB dynamic range and 10-20dB reduction in low-frequency thermal drift.
- Supports packetization with less than 1s time intervals "low**latency**" data to provide data with minimal delay. These data are transmitted in addition to the standard 1s packetized data.

Selected Unique Features



Accelerometer Orientation & Configuration







New Pebble Digitizer/Datarecorder



USB, SD Card & Console Connector



2.5" thick, 3" tall, 5.8" wide





All internal sensors are mutually aligned, and no mass lock or mass centering are necessary. The cable is Y-terminated at the surface to be used with a 6-channel digitizer: best matched with Q8, Q330S+ and Obsidian8X datalogger.

Selected Episensor Features

- Low noise
- Extended bandwidth DC to 200Hz
- User-selectable full-scale range (at time of order)
- Calibration coil (standard)
- Double-stage transient protection

Selected <u>MBB-2</u> Features

- No mass lock required
- No mass centering required
- Small, portable, 120 second (to 160 Hz) broadband sensor
- Large operational tilt range
- Sensitivity of 1,500 V/(m/s)

The New OMNI Sensor - Features







New OMNI Sensor – Dynamic Range

100

OMNISensor OMNIPLot



The OMNISensor covers more than 220 dB velocity dynamic range (205 dB) acceleration) in one watertight enclosure, with one marine connector, one cable, for posthole and borehole installations. No earthquake of interest will be too small to be lost or too large to be off scale.

LOCAL M1.5	\land
LOCAL M3.5	\land
LOCAL M5.5	
LOCAL M7.5	\sim
REGIONAL M1.5	\land
REGIONAL M3.5	\land
REGIONAL M5.5	, ^*-
REGIONAL M7.5	\sim
4g HypoSensor CLIP	\land
4g HypoSensor Noise Noise	\land
MBB-2 CLIP	$\mathbf{\wedge}$
MBB-2 Noise	\land
MODEL-NLNM	\land

Frequency (Hz)	8.88 12 8.88
RMS Acceleration (dB, _	8 JY 17.99

Test Measurements at 300 m (top 6 traces) & 600 m depth at Yeonsei University, South Korea of a M = 2.4 Korea event on 05/30/2021 (top 3 traces from BB seismometer)









· · ·	
and the land of the second sec	YSBJ TRE
	THE REPORT OF LED.
	00:00:00:00
1 1	
	100000000000
water to any list brind out of a	VIEL BER WALL
dis allowed to be a loss	WAT 30 TISM, 2021
	00:00:00:00
- 12 B	
	· · · ·
the second second second second	Senter SET ATTS
and the second second	WAY 30 (150), 2021
	00:00:00:00
ويحجب والمتابية والاستراق	Without VIBL DF.
A DESCRIPTION OF THE OWNER OWNER OF THE OWNER OWNER OF THE OWNER	WAY 30 11501 2021
	00.00.00.000
	00.00.00000
	YSB3 THN
-	the second s
	00-00-00 000
	04.00.00000
	V903 TV7
-	Talba Ing
and the second second second	and any statistic resta
	00:00:00:0000
A	
	1000
anter anter anter anter	A STATE OF THE OWNER OF
the set has been and a	WWY 30 (130), 2021
	00:00:00:00
-	
· · ·	
	1 1
	1981 . TP1
	NEW TEL
	17986 179 87 30 (130) 2021 00:00:00.000
	1386 TEN 1647-30 (130); 2021 00:00:00:000
	19月前 円列 1月前 円列 1月前 円列 1月前一日列 1月前一日列 1月前一日列 1月前 円列 1月前 円列 1月前 円列 1月前 日列 1月前 日 1月前 日 1月前 1月前 日 1月前 日 1月前 1月前 1月前 1月前 1月前 1月前 1月前 1月前 1月前 1月前
	00:00:0000
n and a standard and a standard and a standard and a standard a standard a standard a standard a standard a sta	13985 07.
1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	200:00:00000 00:00:00000
en and an	YSEE 1131. WH 30" (Cuty, Arc) 0:10:00000 YEES 117. 0:10:00000 YEES 117. 0:10:00000
and and a second se	1310 1310 1310 1670-300 1500; 2021 00:00:00.000 1720-50 1720-50 1720-50 00:00:00000
n viente de la companya de la compa	
I	1310 1310 00:00:00.000 7310 7310 7310 7310 7310 7310 7310 7
1	7395 TB octooloo 730 TB octooloo 730 TB octooloo 730 TB octooloo 7395 TH
	7395 TB WH 30 (CD) 2021 0:00000 7395 TF 0:00000 7395 TF 7395 TF 7395 TF 7395 TF 7395 TF 7395 TF 7395 TF
	Y395 TH octroscoloc 70 (100) 401 00 (100) 00 00 (100)
I	Y395 TH 00:00:00 00:00:00 00:00:00 Y395 TH Y395 TH Y395 TH Y395 TH 00:00:00:00 Y395 TH 00:00:00.00 Y395 TH
	Y395 TB 03:00:00000 03:00:00000 03:00:0000 03:00:0000 03:00:0000 Y395 THC Y395 THC Y395 THC Y395 THC Y395 THC
	Y395 113 W1730 (100) 2021 00:00:00:0000 Y395 116 Y395 116 Y395 116 Y395 116 Y395 116 Y395 116 Y395 116
	Y395 TB od:to:color Y395 TF od:to:color Y395 THC Y395 THC Y395 THC Y395 THC Y395 THC Y395 THC Y395 THC
	Y395 TF WF 30 (CD) 201 00:00:000 Y395 TF 00:00:0000 Y395 TF Y395 TF
	Y385 TE 03:00:00000 73:00:00000 73:00:0000 73:00:00000 73:00:00000 73:00:00000 73:00:00000 73:00:00000 73:00:00000
	Y395 TF5 WF 30 (100) 201 00:00:0000 Y395 TF5 V6:00:0000 Y395 TF5 V6:00:00000 Y395 TF5 V6:00:00000 Y395 TF5 V6:00:00000 V395 TF5 V6:00:00000 V395 TF5 V6:00:00000 V395 TF5 V6:00:00000 V395 TF5 V6:00:00000 V395 TF5 V6:00:00000 V395 TF5 V6:00:00000 V6:00:0000 V6:00:00000 V6:00:0000 V6:00:00000 V6:00000 V6:00000 V6:00000 V6:000000 V6:000000 V6:000000 V6:00000 V6:000000 V6:000000 V6:000000 V6:000000 V6:000000 V6:000000 V6:000000 V6:000000 V6:000000 V6:000000 V6:0000000 V6:0000000 V6:0000000 V6:00000000 V6:0000000 V6:0000000000 V6:00000000 V6:00000000 V6:000000000000000 V6:000000000000000000000000000000000000
	Y395 TB 00:00:00000 Y395 TF 00:00:0000 Y395 TF 00:00:0000 Y395 TF 00:00:0000 Y395 TF 00:00:0000 Y395 TF 00:00000 Y395 TF 00:000000 Y395 TF 00:0000000 Y395 TF 00:000000 Y395 TF 00:000000 Y395 TF 00:000000 Y395 TF 00:0000000 Y395 TF 00:0000000 Y395 TF 00:00000000000 Y395 TF 00:0000000000000000000000000000000000
	Y395 TF3 0:10:00120 Y395 TF5 0:10:00120 Y395 TF5 Y395 TF5 Y395 TF5 0:10:00120 Y395 TF5 0:10:00120 0:10:0000 0:10:00000 0:10:0000 0:10:0000 0:10:0000
	YSP5 TB WF 35 (CD), 2021 00:00:00000 YSP5 TF 00:00:00000 YSP5 THE YSP5 THE VSF 35 (CD), 0021 00:00:00000 YSP5 THE WF 30 (CD), 0021 00:000000 WF 30 (CD), 0021 00:000000
	Y395 TB WF 30 (100) Y395 TE 0:0:0:000 Y395 TE 0:0:0:000 Y395 TH Y395 TH 0:0:0:0000 Y395 TH 0:0:0:0000 Y395 TH 0:0:0:0000 WF 30 (100) 2021 WF 3
	YSB5 THE YSB5 T
	Y395 (15), 22 0:0:00000 Y395 (15), 22 0:0:00000 Y395 (15), 22 0:0:00000 Y395 (15), 22 0:0:00000 Y395 (15), 22 0:0:00000 W130 (15), 22 W130 (15), 22 W130 (15), 22 W130 (15), 22 W130 (15), 22
	Y395 TB W7355 TC 00:00:000 Y395 TF W7365 TH W7365 TH W7365 TH W7365 TH W7365 TH W7365 TH W7365 TH W736 (15), 2021 00:00:00000 W755 TH W736 (15), 2021 00:00:00000

Headquarters, Corporate, Kinemetrics, Pasadena, California – USA Headquarters, Quanterra, Harvard, Massachusetts – USA Headquarters, Metrozet, Los Angeles, California – USA Headquarters, BRTT, Boulder, Colorado – USA Network Operation, Denver, Colorado – USA

Office in Abu Dhabi Network Operation, Abu Dhabi Network Operation, Saudi Arabia

Address

Kinemetrics 222 Vista Avenue Pasadena, CA 91107 P ct Lir

Direct Line: +1-626-795-2220 Fax: +1-626-795-0868 sales@kmi.com



Thank You!



Phone & Fax

Social Media

facebook.com/osskinemetrics twitter.com/osskinemetrics linkedin.com/company/kinemetrics an____